HTX-200 Quick Reference		
		PTT to store.
Tone Set	18	F &▼. F+ ▲, to select option, ▲▼to change. tC to select TX tone
Enter freq	23	F+▲ (2nd digit from left flashes), then ▲or▼. F+▲ for next digit
Open Sqlch	24	MO
Dup on/Off	27	F+SC/RPT
Offset +-	28	F+SC. F+MO to change
Input mon	28	F+PTT
Store mem	29	MR. MR & mem location appear. ▲▼for mem location, select freq, offset & tone. PTT to store.
Call mem	30	MR, ▲▼. MR for VFO.
Clear mem	30	MR. ▲▼ to mem. F+MR. Mem# flashes. F to clear.
Lock	38	F+Lock, F+Lock to unlock

HTX-200 Quick Reference		
		PTT to store.
Tone Set	18	F &▼. F+ ▲, to select option, ▲▼to change. tC to select TX tone
Enter freq	23	F+▲ (2nd digit from left flashes), then ▲or▼. F+▲ for next digit
Open Sqlch	24	MO
Dup on/Off	27	F+SC/RPT
Offset +-	28	F+SC. F+MO to change
Input mon	28	F+PTT
Store mem	29	MR. MR & mem location appear. ▲▼for mem location, select freq, offset & tone. PTT to store.
Call mem	30	MR, ▲▼. MR for VFO.
Clear mem	30	MR. ▲▼ to mem. F+MR. Mem# flashes. F to clear.
Lock	38	F+Lock, F+Lock to unlock

HTX-200 Quick Reference		
		PTT to store.
Tone Set	18	F &▼. F+ ▲, to select option, ▲▼to change. tC to select TX tone
Enter freq	23	F+▲ (2nd digit from left flashes), then ▲or▼. F+▲ for next digit
Open Sqlch	24	MO
Dup on/Off	27	F+SC/RPT
Offset +-	28	F+SC. F+MO to change
Input mon	28	F+PTT
Store mem	29	MR. MR & mem location appear. ▲▼for mem location, select freq, offset & tone. PTT to store.
Call mem	30	MR, ▲▼. MR for VFO.
Clear mem	30	MR. ▲▼ to mem. F+MR. Mem# flashes. F to clear.
Lock	38	F+Lock, F+Lock to unlock

HTX-200 Quick Reference		
		PTT to store.
Tone Set	18	F &▼. F+ ▲, to select option, ▲▼to change. tC to select TX tone
Enter freq	23	F+▲ (2nd digit from left flashes), then ▲or▼. F+▲ for next digit
Open Sqlch	24	MO
Dup on/Off	27	F+SC/RPT
Offset +-	28	F+SC. F+MO to change
Input mon	28	F+PTT
Store mem	29	MR. MR & mem location appear. ▲▼for mem location, select freq, offset & tone. PTT to store.
Call mem	30	MR, ▲▼. MR for VFO.
Clear mem	30	MR. ▲▼ to mem. F+MR. Mem# flashes. F to clear.
Lock	38	F+Lock, F+Lock to unlock